

Wireless Charger
Operation Manual



- Adapter
- USB Cable
- Connector For Power Supply
- 4 Charging Area
- 6 Indicator Light Area
- Operate Manual

First of all, thanks sincerely for buying our products.

- 1) For you safety, please read this manual carefully before using.
- Please do read the attentions before using.
- 3) Please make sure that you have write down the selling date and shop name, and safe-keep them together with operation manual and warranty card.

Attention (Please obey them)

To protect people from harm and property loss, we make a clear explanation on what you do should obey:

1. This explanation is made according to the harm which caused by wrong use and degree of damage.



Warning! There are concerning the possibilities of death and severe wound Attention! There are contents concerning the occurence of slight wound and property damage

2. Things you have to do, which is marked as bellow (Mark examples)









People who use heart-birth maker should consult your doctor before you use this product



People who use the heart-birth-maker please leave it at a distance of 22CM from the place where you install your heart-birth-maker. The electromagnetic wave have influence on heart-birth-maker's work.

Do not put it into water or any other liquid product, Do not make it wet

It may lead to heat, electric shock

Please make sure you have fully connect the AC adapter

It may lead to heat, fire and electric shock, If it does not fit into the AC adapter

Do not pull the AC adapter out with wet hands

lt may lead to fire and electric shock

The protectors should teach their children the complete right way before letting them use this

It may lead to electric shock and wound
Please clear the dust piled up on the AC adapter at

It may lead to heat, electric shock if there is too much dust or other things accumulating on it Do not lay anything between the wireless charging pad and the charging machine

N It may lead to heart, fire and burn.

Do not use it in places out of the temperature ranging from -20 $^{\circ}$ -40 $^{\circ}$

N It may lead to fire

regular intervals

Do not charge in places where the sun shine directly or with high temperature

N It may lead to heat, fire and burn

Please do not use and keep it in wet and dust places

It may lead to heat, fire and electric shock Do not surpass the rated value when using the plug and other wiring layout

It may lead to fire

Do not make any breakage on the AC adapter

It may lead to heat, fire and electric shock when using broken AC adapter

Do not charge when the product is covered by coarse cotton cloth

No not use travel converter

N It may lead to heat, fire and electric shock

Do not lay the charging machine loaded with other things in places that are easy to fall

New It may lead to heat, fire and electric shock
Please take the AC adapter off the plug when it's not used

It may lead to fire and electric shock

Do not use broken adapters and loose when connected to the plug

N It may lead to fire and electric shock

Do not put any aluminum seal or other mental stuff on the wireless charging pad

It may lead to heat, fire, burn and wound caused by breakage on this product

Please charge in steady horizontal level places

It may lead to wound if it fall down

Tips for use

- 1. Please refer to the operation Manual and put the charging machine in charging area. All you have to do is put it in the charging area, it will start charging regardless of the place and direction. Try to put it near the charging center as close as possible.
- 2. When the charge is almost finished but not yet, it will stop charging, this is normal.
- 3. When the product which is under charging condition is mixed with television and radio noise ,please keep the product away form television and radio for more than 1 M
- 4. It will affects wireless changing if the charging device is covered with thick protecting sleeves, you'd better take it off when charging.



Do not lay the magnetic card, magnetic record media and precise machine too close to the product!!

If you put the wireless charging pad close to magnetic card and magnetic record medias, the product may have influence on the magnetic and make those recorded data disappear, and hand watch or other precise machine may break down, so do not put them close to the product.

Product advantages

- Once you put this QI-marked charging machine in the charging area ,it will start to charge persistently.
- This QI-marked products, fit the wireless charging standard set by the WPC.
- This product also can charge the charging machine which consist of QI-marked power plug and charging machines. (There are conditions that this product does not charge well for some machine please read the operation manual carefully before using it.)



OI and OI mark, are the trade marks of WPC

This product applies for QI standard receiver











AC adapter connection method

- 1. Connect the USB cable to wireless charging pad USB slots, please ensure that put the most inside.
- 2. Insert the USB cable into the ac adapter, when it powers on, power LED will light up, when power on, wireless charging pad will have voice prompt, enters the charging status.

The charging method of charging machine

- 1. Lay the QI-marked charging machines in the charging area.
- 2. The green light means it starts to charge, you should move the charging machine in the charging area to get it recognized.
- 3. If the product does not charge, Please try to replace the machine on it.

Accessories / components name and application methed

1 USB Cable

2. Wireless charging pad

3.AC adapter







